



TS-2800 Configuration Information Card

MANU0213-01 - Rev. A - October 1997

Switch Information

Building/Room/Rack	
Unit Number	
Serial Number	
MAC Address	

Contact Information

Network Administrator	
Telephone	
Fax	
Service Contact	
Telephone	
Fax	
FORE Technical Support:	
Phone	800-671-FORE or 412-635-3700
Fax	412-742-7900
Email	support@fore.com

Reset Button

Pressing the **Reset** button resets the hardware and software and clears all tables and memory, including the address tables. It does not clear those values stored in non-volatile random access memory (NVRAM) and does not run self-diagnostics.

Port Information

Base Port	Cable Destination Address Building/Room/Rack Distribution Panel/Coordinate
EIA-232	
UFC Port	Cable Destination Address Building/Room/Rack Distribution Panel/Coordinate
1-1	
1-2	
2-1	
2-2	
2-3	
2-4	
3-1	
3-2	
3-3	
3-4	
4-1	
4-2	
4-3	
4-4	
5-1	
5-2	
5-3	
5-4	
6-1	
6-2	
6-3	
6-4	

UFC Port	Cable Destination Address Building/Room/Rack Distribution Panel/Coordinate
7-1	
7-2	
7-3	
7-4	
8-1	
8-2	
8-3	
8-4	

UFC Port LEDs

Label	State	Meaning
Connect	On	Connected.
	Off	Disabled.
	Blinking	Attempting to connect.
FDX	On	Port is set to FDX mode.
Tx/Rx	On	Data is being transmitted or received.

Status LEDs

Label	Function (color)	State	Meaning
AC OK	AC Power	On	AC power input is good.
	(green)	Off	AC power output is bad.
DC OK	DC Power	On	DC power output is good.
	(green)	Off	DC power input is bad.
I	Power	On	Card power is good.
	(green)	Off	Card power is bad.
OK	OK	On	Operating correctly.
		Off	Not operating correctly.
		Blink-ing	Diagnostics in progress.
none	Fault (amber)	On	A diagnostic failure has occurred.
		Off	No errors detected.
		Blink-ing	Diagnostics in progress.

Status Display

Message Type		T		test number		POST	
		1	2	3	4		
Display Character		System Component ¹		Action ²		Operational	
		O		K			

1. System Component:

- F1 Fan1
- F2 Fan2
- P1 Power supply 1
- P2 Power supply 2
- PC Processor card
- Sx UFC in slot x (1-8)
- IA Fuses 3 and 4
- IB Fuses 1 and 2
- IC Fuses 7 and 8
- ID Fuse 6

2. Action

- H Hardware failure. Replace the component.
- Cx Software failure. Download new software and reconfigure.
- C1 - Boot image
- C2 - Main image
- X UFC is not installed in a valid slot. Move the UFC to a valid slot.
- ? The failure cannot be isolated to a specific component.
- OK System is operating correctly.